



## SAFETY PRECAUTIONS

- Read all instructions.
- **DO NOT** use on an infant or on an animal.
- **DO NOT** use on or by an invalid, a sleeping or unconscious person, a person sensitive to heat.
- **DO NOT** use on areas of insensitive skin.
- Burns can occur regardless of control setting.
- Check skin under pad frequently.
- **DO NOT** use if any visible damage is apparent (Cracks, tears or exposed wires and heating sheet).
- **Must** instantly turn off the heating pad and Unplug when overheat or charred flavor in use.
- **DO NOT** use pins or other metallic means to fasten this pad in place.
- **DO NOT** bunch, sit on or against or crush pad-avoid sharp folds.
- Never pull this pad by the supply cord.
- **DO NOT** use the cord as a handle.
- This unit should **NOT** be used by children without adult supervision.
- Unplug when not in use.
- **DO NOT** use this pad with liniment, salve or ointment preparations, especially ones that contain heat producing ingredients. Skin burns could result.
- **DO NOT** bend or pinch cord and **DO NOT** use if cord is damaged.
- **DO NOT** heap and cover anything on the heating pad when use.
- **DO NOT USE WET. DO NOT** reconnect the heating pad or use it until it is COMPLETELY dry.
- **DO NOT** dry clean, wrung out, machine dried, ironed.
- Never leave the appliance unattended, especially if children are present.
- Loop cord loosely when storing. Tight wrapping may damage cord.
- Power adapter with a over 5V=3A output is prohibited.
- Save these instructions.

## HEATING PAD OPERATION

- **Cable:** Please use the supplied original cable.
- **Connecting:** The type-c port is connected to heating pad and the USB port is connected to the power supply.
- **Power source:** Rated power is 5V=2.6A. Please work with a quality 5V=2A or 5V=3A power adapter or power source. Note: Power source could be a USB port on a computer, power bank, or wall adapter with a 5V=2A or 5V=3A output. Please always use with a suitable power source and avoid overheating to ensure safe use.
- **Turn on the product:** long press the power button for 2 seconds until the indicator light turns red, color red shines constantly indicating that the product has been activated.
- **Heating levels setting:** the product has 3 heating levels which can be adjusted by briefly pressing the power button. The heating levels can be identified by color.
- **Turn off the product:** Press the power button for 2 seconds until the indicator light turns off, indicating that the product has been turned off.
- **Auto shut-off feature:** The heating pad includes auto shut-off feature to prevent overheating.



- Red:** highest heating level — 60-min auto-off  
**Blue:** medium heating level — 90-min auto-off  
**Green:** lowest heating level — 120-min auto-off

## CLEANING, CARE AND MAINTENANCE


- **Unplug and Disconnect:** Before cleaning, always unplug the heating pad from the power source and disconnect it from any electrical outlets.
- **Surface Cleaning:** For surface cleaning, use a slightly damp cloth with a mild detergent to wipe the surface of the heating pad. Avoid using A dripping wet rag, harsh chemicals or abrasive cleaners, as they may damage the pad.
- **Avoid Submerging:** Do not submerge the heating pad in water or any other liquid. This heating pads are not designed to be waterproof, and immersing them in water can lead to electrical hazards.
- **Dry Thoroughly:** After cleaning, ensure that the heating pad is completely dry before reconnecting it to the power source. Moisture can lead to electrical shorts or other safety issues.
- **Avoid Folding or Crimping:** When storing the heating pad, avoid folding or crimping it, as this can damage the internal heating elements. Store it in a flat position to maintain its integrity.
- **Storage:** unplug the power supply and remove the type-c cable, and store the heating pad in a dry, safe, clean and cool place after cleaning up.

## TROUBLE-SHOOTING

### No Heat / No Power:

- Please use the supplied original cable.
- Verify no physical damage to the cord, button or pad.
- Verify tight connection.
- Verify AC outlet is functional.
- The power source should be equal to or more than 5V=2A output.
- Restart unit to desired heat level.
- Make sure pad is not folded or bunched in any area.

## ASSEMBLY INSTRUCTION



Model	3185T
Manufacturer	TWINCO (Xiamen) Office Supplies Co., Ltd.
Address	No. 107, Xiaguang Road, Hai Cang District, Xiamen City, China
Input Power	5V = 2.6A
Output Power	13W
Production Date	See carton
Made in China	

